

SERVICE KIT E UTENSILI DI MONTAGGIO

SERVICE KIT AND TPMS MONTING TOOLS

SERVICE KITS ET OUTILS POUR MONTAGE TPMS

Raccomandazioni per la manutenzione ordinaria dei sensori TPMS OE

Recommendations for the ordinary maintenance of OE TPMS sensors

Ad ogni sostituzione degli pneumatici, i TPMS Service Kit devono essere utilizzati per sostituire quelle componenti che sono soggette ad usura quali la valvola in gomma completa con la vite o nel caso di valvola in metallo il dado, la guarnizione, il meccanismo interno ed il coperchietto. Quando si cambiano gli pneumatici su una vettura senza TPMS è normale sostituire le valvole; pertanto, anche in presenza di sensori TPMS, bisogna effettuare la corretta manutenzione. Questa azione, previene rotture e evita danni più importanti e molto costosi che potrebbero comportare anche la sostituzione dell'intero sensore.

Infatti, se perfettamente mantenuti, i sensori non devono essere sostituiti ad ogni cambio pneumatici. La loro vita media è estremamente alta e le batterie durano anche fino a 10 anni, in funzione anche dell'utilizzo del veicolo. Quindi, ad ogni cambio devono essere tassativamente sostituite le parti soggette ad usura.

At every replacement of tyres, TPMS Service Kits must be used to replace the components subject to wear like the complete rubber valve with screw or in case of metal valve the nut, the seal, the core and the cap. When tyres are changed on a car without TPMS, it is normal replacing valves; therefore, also in the presence of TPMS sensors, a correct maintenance has to be executed. This action prevents breakages and avoid more important and more expensive damages which could require also the replacement of the whole sensor.

In fact, if perfectly maintained, sensors do not have to be replaced at every change of tyres. Their average life is extremely high and batteries last up to 10 years, also according to the use of the vehicle. Therefore, at every change, the parts subject to wear must be imperatively replaced.



SERVICE KIT E UTENSILI DI MONTAGGIO
SERVICE KIT AND TPMS MONTING TOOLS
SERVICE KITS ET OUTILS POUR MONTAGE TPMS

**RICAMBI
 UNIVERSALI**

**UNIVERSAL
 SERVICE KIT
 KIT SERVICE
 UNIVERSEL**

- **2 KIT UNIVERSALI = 94% COVERAGE**
- **RIDUZIONE PARTI A MAGAZINO**
- **SEMPLIFICAZIONE SCELTA RICAMBIO**

- **2 UNIVERSAL KITS = 94% COVERAGE**
- **REDUCTION OF SPARE PARTS IN STOCK**
- **SIMPLIFICATION OF SPARE PART CHOICE**

- **2 KITS UNIVERSELS = 94% COUVERTURE**
- **RÉDUCTION DES PIÈCES DE RECHANGE EN STOCK**
- **SIMPLIFICATION CHOIX RECHANGE**




Diagram illustrating the assembly of the universal snap: a circular component with a hole and a protrusion is combined with another circular component with a matching hole and protrusion to form a complete snap.

Universal snap

Italmatic p/n 3040033QX	10 PCS / box
----------------------------	--------------



Diagram illustrating the assembly of the universal clamp, showing various components including a threaded cap, a nut, a washer, a spring, and a seal.

Universal clamp

Italmatic p/n 3040033QX1	10 PCS / box
-----------------------------	--------------

SERVICE KIT E UTENSILI DI MONTAGGIO
SERVICE KIT AND TPMS MONTING TOOLS
SERVICE KITS ET OUTILS POUR MONTAGE TPMS

**VALVOLE CLAMP-IN
 PER TPMS**

**CLAMP-IN VALVES FOR
 TPMS**

**VALVES CLAMP-IN
 POUR TPMS**

 <p>1x</p>	 <p>1x</p>	 <p>1x</p>	 <p>1x</p>				
Clamp-in Schrader Gen-Alpha		Clamp-in Conti TG1C		Clamp-in Conti TG1C		Clamp-in Schrader Gen4	
Italmatic p/n 3040033H1	OE p/n 8001	Italmatic p/n 3040033N1	OE p/n A2C59517072	Italmatic p/n 3040033N2	OE p/n A2C59517073	Italmatic p/n 3040033W1	OE p/n 5024
 <p>1x</p>	 <p>1x</p>	 <p>1x</p>	 <p>1x</p>				
Clamp-in Schrader fixed angle		Clamp-in Schrader fixed angle black		Clamp-in Schrader variable angle		Clamp-in Conti TG1B	
Italmatic p/n IT-200-V1	OE p/n 5061	Italmatic p/n IT-200-V1B	OE p/n 5061B	Italmatic p/n IT-300-V1	OE p/n 5056/5060	Italmatic p/n 3040033K1	OE p/n -
 <p>1x</p>	 <p>1x</p>	 <p>1x</p>	 <p>1x</p>				
Clamp-in TRW		Clamp-in HUF Gen2 L=43mm		Clamp-in HUF Gen2 L=48mm		Clamp-in HUF Gen2 L=49mm	
Italmatic p/n 3040033R1	OE p/n -	Italmatic p/n 3040033V1	OE p/n RDV021	Italmatic p/n 3040033V2	OE p/n RDV022	Italmatic p/n 3040033V3	OE p/n RDV023
 <p>1x</p>	 <p>1x</p>	 <p>1x</p>	 <p>1x</p>				
Clamp-in HUF Gen2 L=51mm		Clamp-in HUF Gen2 L=56mm		Clamp-in Conti TG1B		Clamp-in Conti TG1B	
Italmatic p/n 3040033V4	OE p/n RDV024	Italmatic p/n 3040033V5	OE p/n RDV025	Italmatic p/n 3040033K2	OE p/n -	Italmatic p/n 3040033K	OE p/n -

SERVICE KIT E UTENSILI DI MONTAGGIO
SERVICE KIT AND TPMS MONTING TOOLS
SERVICE KITS ET OUTILS POUR MONTAGE TPMS



1x

Service kit Conti TG1C HKMC

Italmatic p/n
3040033J

OE p/n
S180014531A



1x

Service kit Conti TG1B

Italmatic p/n
3040033K3

OE p/n
A2C59511332
S180014541A



1x

Service kit Schrader Gen2/3

Italmatic p/n
3040033L

OE p/n
5016



1x

Service kit Schrader Gen-Alpha

Italmatic p/n
3040033M

OE p/n
5017/5029



1x

Service kit Conti TG1C Renault

Italmatic p/n
3040033N

OE p/n
S180084500A



1x

Service kit Schrader Gen-Alpha

Italmatic p/n
3040033P

OE p/n
5019



1x

Service kit Schrader Gen-Alpha

Italmatic p/n
3040033E1

OE p/n
5027



1x

Service kit Schrader Gen-J

Italmatic p/n
3040033G1

OE p/n
5030



1x

Service kit Schrader Gen4

Italmatic p/n
3040033S1

OE p/n
5025



1x

Service kit Conti TG1C

Italmatic p/n
3040033S

OE p/n
S180084520A



1x

Service kit Conti TG1C HKMC

Italmatic p/n
3040033R

OE p/n
S180084510A



1x

Service kit Conti TG1C Mazda

Italmatic p/n
3040033X

OE p/n
A2C59507828



1x

Service kit Pacific

Italmatic p/n
3040033X1

OE p/n
-



1x

Service kit HUF Gen 2

Italmatic p/n
3040033V7

OE p/n
-



25x

Valve Core

Italmatic p/n
3040033Y

OE p/n
-



25x

Grey Cap

Italmatic p/n
3040033Z

OE p/n
A2C59507828